

Ghid rapid PNI Finger 300

➤ **Resetați terminalul la setările din fabrică:**

- **Pasul 1:** Terminalul are un comutator anti-sabotaj magnetic, ce trebuie deconectat (**magnet dreptunghiular**). Deconectați apoi alimentarea terminalului. (**Comutatorul magnet este situat în partea din spate a terminalului**).
- **Pasul 2:** Conectați alimentarea terminalului fără comutatorul magnet. Veți auzi primul semnal sonor după 30 de secunde apoi un al doilea semnal sonor, moment în care trebuie să apropiati magnetul de comutatorul magnetic de 3 ori . (**Fiecare apropiere, va genera un beep de confirmare**).
- **Pasul 3:** dispozitivul restabilește setările din fabrică. Parola inițială de administrator este 1234

➤ **Modificare parola de administrator:**

- **Pasul 1:** Apasati [*] si [#] 1234
- **Pasul 2:** Apasati [8]. (Ledul indicator se aprinde verde și se aude un beep.)
- **Pasul 3:** Introduceti noua parola de administrator din 4 cifre.
- **Pasul 4:** Introduceti din nou parola de administrator pentru confirmare/autentificare
- **Pasul 5:** Succes. (Ledul indicator se aprinde verde și se aude un beep lung.)
- **Pasul 6:** Iesire. (Dispozitivul ieșe automat din procedura cand operatiunea este finalizata).

➤ **Adaugare Utilizatori:**

- **Pasul 1:** Apasati [*] si [#] si [parola sistem]
- **Pasul 2:** Apasati [1]. (Ledul indicator se aprinde verde și se aude un beep lung)
- **Pasul 3:** Introduceti un ID de utilizator (3 cifre) și apasati [#]
- **Pasul 4:** Înregistrați amprenta sau card. (Puneti degetul de 3 ori pe cititor pentru amprenta sau apropiati cardul de aparat.)
- **Pasul 5:** Adaugare Utilizatori reusita. (Ledul indicator se aprinde verde și se aude un beep lung.)
- **Pasul 6:** Iesire. (Apasati [*] pentru iesire.)

➤ **Stergere toti utilizatorii:**

- **Pasul 1:** Apasati [*] si [#] si [parola sistem]
- **Pasul 2:** Apasati [9]. (Ledul indicator se aprinde verde si se aude un beep lung.)
- **Pasul 3:** Apasati [9]. (Ledul indicator se aprinde verde si se aude un beep lung.)
- **Pasul 4:** Stergerea tuturor utilizatorilor reusita (Ledul indicator se aprinde verde si se aude un beep lung.)
- **Pasul 5:** Iesire. (Dispozitivuliese automat din procedura cand operatiunea este finalizata.)

➤ **Stergere utilizatori:**

- **Pasul 1:** Apasati [*] si [#] si [parola sistem]
- **Pasul 2:** Apasati [2]. (Ledul indicator se aprinde verde si se aude un beep lung.)
- **Pasul 3:** Introduceți un ID de utilizator, apăsați amprenta sau glisați cardul și [#]
- **Pasul 4:** Determină dacă utilizatorul este autentic
- **Pasul 5:** Utilizatorul este sters (Ledul indicator se aprinde verde si se aude un beep lung.)
- **Pasul 6:** Iesire. (Apasati [*] sau nu accesati dispozitivul pentru 20 de secunde).

➤ **Adaugare parola la un utilizator inregistrat:**

- **Pasul 1:** Apasati [*] si [#] si [parola sistem]
 - **Pasul 2:** Apasati [3].
 - **Pasul 3:** Introduceti un ID de utilizator inregistrat si apasati [#]
 - **Pasul 4:** Introduceti o parola din 6 cifre. (*Dacă parola are mai puțin de șase cifre, trebuie să introduceti parola și sa apasati[#]*)
 - **Step 5:** Introduceti parona din nou.
 - **Step 6:** Iesire. (Apasati [*] pentru iesire.)
-
- **Acces prin Parola:** Introduceti un ID de utilizator inregistrat + [#] + (parola) + [#]

Quick Guide PNI Finger 300

➤ **Reset the terminal to factory settings:**

- **Step 1:** The terminal has a magnet tamper switch please disconnect it. Later disconnect the power of terminal. (***The magnet tamper switch is located in the back of the terminal.***)
- **Step 2 :** Connect the power of terminal without the magnet tamper switch. You'll listen the first beep after 30 seconds you can listen the second beep, in this moment you must swap the tamper three times. (***Each swaping it, the device will produce a beep.***)
- **Step 3:** The device restore factory settings. The initial administrator password is 1234

➤ **Change Administrator Password:**

- **Step 1:** Enter [*] and [#] 1234
- **Step 2:** Press [8]. (The indicator turns green and makes a beep.)
- **Step 3:** Enter a new administrator password.
- **Step4:** Enter the new administrator password again for authentication
- **Step 5:** Succeeded. (The indicator turns green and makes a long beep.)
- **Step 6:** Exit. (The device automatically exits the process when the operation is completed.)

➤ **Add Users:**

- **Step 1:** Enter [*] and [#] system password
- **Step 2:** Press [1]. (The indicator turns green and makes a long beep.)
- **Step 3:** Enter a user ID and [#]
- **Step4:** Register fingerprints or cards. (Press a finger three times to get a fingerprint or swipe the card once.)
- **Step 5:** Adding Users is successful. (The indicator turns green and makes a long beep.)
- **Step 6:** Exit. (Press [*] to exit.)

➤ **Delete All Users:**

- **Step 1:** Enter [*] and [#] system password
- **Step 2:** Press [9]. (The indicator turns green and makes a long beep.)
- **Step 3:** Press [9]. (The indicator turns green and makes a long beep.)
- **Step 4:** Deleting All Users is successful. (The indicator turns green and makes a long beep.)
- **Step 5:** Exit. (The device automatically exits the process when the operation is completed.)

➤ **Delete Users:**

- **Step 1:** Enter [*] and [#] system password
- **Step 2:** Press [2]. (The indicator turns green and makes a long beep.)
- **Step 3:** Enter a user ID, press the fingerprint or swipe the card, and [#]
- **Step 4:** Determine whether the user is authentic
- **Step 5:** The user is deleted (The indicator turns green and makes a long beep).
- **Step 6:** Exit. (Press [*] or do not operate the device within 20 seconds).

➤ **Add Password to the registered user:**

- **Step 1:** Enter [*] and [#] system password
 - **Step 2:** Press [3].
 - **Step 3:** Enter a registered user ID and [#]
 - **Step4:** Enter six digits of password. (*If the password less of six digits you must to enter the password and [#]*)
 - **Step 5:** Enter the password again
 - **Step 6:** Exit. (Press [*] to exit.)
-
- **Acces by Password:** Enter a registered user ID + [#] + (password) + [#]