



Sprinkler timer PNI WT08

User manual



CONTROL BUTTONS




Maximum operating pressure: 80PSI For irrigation use only

INSTALLING THE BATTERY

2 × AAA ALKALINE BATTERIES ARE RECOMMENDED

Remove the battery cover – keep battery compartment dry – install the 2 × AAA Battery by lining up the connections. Place the battery inside the compartment and reinstall the battery cover.

NOTE: When battery is first connected, it takes up to 1 minute for the battery indicator to assess the battery strength.



MAINTENANCE


Remove and clean the screen washer on inlet side of the timer every few months.

Remove battery if timer is not used for an extended time.

In freezing conditions, un-install the timer and bring it indoors to prevent damage.

HOW TO INSTALL


Attach the timer inlet to the outdoor faucet/spigot turning clockwise – hand tighten only. From the timer outlet connect a drip irrigation system or a garden hose.



Timer inlet:
3/4 in. female hose thread with screen washer

Timer outlet:
3/4 in. male hose thread


A SETTING – TIME & DAY



Set the current time
Push "SET CLOCK" button to select hours then push (OK) button to set minutes. Adjust using +/- AM/PM is set by increasing or decreasing the hour and minutes.

Set the current day
Push (OK) until the square "Mo" or any other day flashes under the day of week. Set the day of the week using +/- After setting push (OK) to confirm

B SETTING – START TIMES



Push "START TIME" button and select (Clock icon) Starts (start time).

Adjust hours using +/- then push (OK) to adjust minutes.

You can set up to 4 start times.


C SETTING – WATERING DURATION



Push (OK) button and select (Hourglass icon) Duration.

Adjust watering time by +/-

Attention: when "hour" appears, it is setting minutes. when there is no "hour" symbol, it is setting seconds



For example:

- 05 → 5 second
- 00:05 → 5 minutes
- 01:05 → 65 minutes

D SETTING – WATERING DAY(S)



Push (OK) button and select (Calendar icon) Days.

Push +/- until the square "Mo" flashes under Monday

Push (OK) to deactivate Monday or keep it active and advance to Tuesday. Do this for each day you would like to water.



E MANUAL OPERATION



To instantly water push "MANUEL" button

Push "MANUEL" button to stop



EU Simplified Declaration of Conformity


ONLINESHOP SRL declares that Sprinkler timer PNI WT08 complies with the Directive EMC 2014/30/EU. The full text of the EU declaration of conformity is available at the following Internet address: <https://www.mypni.eu/products/10092/download/certifications>

Warranty certificate


The commercial guarantee does not affect the rights of the consumer provided by the applicable legislation in force, namely Emergency Ordinance 140/28.12.2021 regarding certain aspects related to contracts for the sale of goods, OG 21/1992 regarding consumer protection with subsequent amendments and additions and Law 296/2004 regarding the consumption code with subsequent changes and additions.



Manual de utilizare



Taste si functii




Presiune maxima suportata: 80PSI

Instalare baterii

Sunt necesare 2 baterii alcaline AAA

Desfaceti capacul de pe compartimentul pentru baterie, instalati bateria si puneti capacul la loc.
Inchideti bine capacul pentru a pastra rezistenta la apa a programatorului.

NOTA: la un minut dupa instalarea bateriei, va fi afisata pe ecran pictograma de baterie incarcata.




Intretinere


Curatati periodic programatorul si conectorii acestuia.
Daca nu folositi programatorul o perioada mai lunga de timp, scoateti bateria din programator.
Daca se anunta conditii de inghet, deconectati programatorul de la instalatia de irigare si depozitati-l la interior.

Instalare

Conectati robinetul de apa la conectorul de intrare al programatorului.
In iesirea programatorului conectati sistemul de irigatii sau un furtun de gradina.



A Setare data si ora




Setare ora

Apasati butonul SET CLOCK pentru a seta ora, apoi apasati (OK) pentru a seta minutele.
Apasati - + pentru a creste sau descreste valoarea.

Setare data

Apasati (OK) pana cand ziua saptamanii ("Mo", "Tu" etc.) clipeste pe ecran.
Apasati - + pentru a selecta ziua saptamanii.
Apasati (OK) pentru a confirma.

B Ora pornire irigare



Apasati butonul START TIME. Pictograma apare pe ecran.
Reglati ora de pornire irigare apasand - + si (OK) pentru a regla minutele


C Durata irigare



Apasati (OK) si selectati DURATION.
Pe ecran apare pictograma

Apasati - + pentru a selecta durata:

05 → 5 secunde
00:05 → 5 minute
01:05 → 65 minute
hour



D Selectare zile de irigare



Apasati (OK) si selectati Days

Apasati - + pana cand "Mo" (monday, luni) clipeste pe ecran

Apasati (OK) pentru a dezactiva ziua de luni sau lasati-o activa si treceti la ziua de marti (Tuesday). Procedati astfel pentru toate zilele saptamanii in care doriti sa udati.



E Irigare manuala



Apasati butonul MANUEL pentru a porni irigare manuala.
Apasati din nou butonul MANUEL pentru a opri irigare manuala.



Declaratie de conformitate simplificata

ONLINESHOP SRL declara ca Programator irigatii PNI WT08 respecta Directiva EMC 2014/30/UE. Textul integral al declaratiei de conformitate UE este disponibil la urmatoarea adresa de internet:
<https://www.mypni.eu/products/10092/download/certifications>

Certificat de garantie

Garantia comerciala nu afecteaza drepturile consumatorului prevazute prin legislatia aplicabila in vigoare, respectiv Ordonanta de Urgenta 140/28.12.2021 privind anumite aspecte referitoare la contractele de vanzare de bunuri, OG 21/1992 privind protectia consumatorilor cu modificarile si completarile ulterioare si Legea 296/2004 privind codul consumului cu modificarile si completarile ulterioare.

