



EZCast is used to play music from USB Drive or your device, modify the password, change the audio output mode, connect to internet and upgrade for your Wireless Music Box.

The latest EZCast is available in GooglePlay and AppStore. Search EZCast in GooglePlay or AppStore to download and install it on your device.





Device Connection

1. Before you start the app, we suggest connect your Android device's WiFi with EZCast Wireless Music Box (SSID displaying as EZMusicxxxx). However, if you skip WiFi connection first, the EZCast will allow you to connect to the Wireless Music Box in app.



- 2. When you opened the app, you can use "Demo mode" or "Find device" to start over to enjoy our features.
- 3. Click "Find device" to discover $\Bar{\text{EZCast}}$ Wireless Music Box and start to cast.
- 4. If you didn't connect EZCast in the beginning, our android app will automatically list the EZCast Wireless Music Box so that you can click it and connect it directly. 5. You will be able to find another EZCast installed phone if they are under the same network, it's a new feature to enhance your mobile phone to an EZCast Wireless Music Box.
- 6. We strongly recommend you to establish EZCast Wireless Music Box WiFi with your home/company network to keep internet surfing since your mobile device's WiFi is linking to EZCast Wireless Music Box.

Play music on Wireless Music Box

Step 1, On your device, go to Settings-> WiFi, connect to EZMusicxxxx.

Step 2, On your device, run EZCast->Tap Search to search EZMusi->Tap EZMusicxxxxx in the device list to connect.





Step 3, Tap Music->Select music from playlist to play on the Wireless Music Box.



EZCast on Windows

· System requirements

CPU	Dual Core 2 GHz or higher (ATOM not supported)
Graphic card	Graphic card with 64MB VRAM or above
OS version	Windows 7, SP1, Windows 8/8.1 and above
PC's WiFi	802.11n (2T2R recommended)

Download

 You can download Windows app from www.iezvu.com



2. Select the version you would like to download.

Device Connection

- 1. Please connect EZCast Wireless Music Box and power on.
- 2. After installation and restart your PC to take affected for our app.
- Before you start the app, we suggest connect your PC's WiFi with EZCast Wireless Music Box (SSID displaying as EZMusicxxxx), then open EZCast.
- 4. Open EZCast and allow access.



5. The EZCast will be listed, select the device ID and connect with it.



Features



Music Streaming

- When you enable music streaming, we will launch file manager so that you can choose the music you want to play to EZCast Wireless Music Box.
- You can use EZCast control bar to adjust the volume and progress bar.
- *Noted that Only the supported audio formats will be played.



EZCast on iOS

System requirements

iOS	iOS 7 and later
Device	All iPhone model after iPhone 4 All iPad model after iPad 2 All iPod touch after iPod touch 4thge- neration

Download

1. You can use QR code scanner app to scan the QR code on display, then you will be redirected to download our app:



2. Or you can search the App name "EZCast" in App Store. (http://goo.gl/TUA7tz)

Device Connection

Before you start up EZCast, connect your iOS device's WiFi with EZCast Wireless Music Box (SSID displaying as EZMusicxxxx).



- 2. After you opened the app, you can use "Demo mode" or "Find device" to start over to enjoy it.
- 3. Click "Find device" to discover EZCast Wireless Music Box and start to cast.
- 4. In the first time of app launching, we will pop up WiFi router list so that you can control your EZCast Wireless Music Box to connect your Home WiFi router to keep internet surfing. (We strongly recommend you to establish EZCast Wireless Music Box WiFi with your home/company network to keep internet surfing since your mobile device's WiFi is linking to EZCast Wireless Music Box).

How add music to EZCast Music playlist for IOS Device

Step 1, Launch iTurns on PC and connect your IOS Device to PC. Click Apps on your ISO device, Select EZCast from the File Sharing apps list, Click Add to add music to EZCast, played.



Step 2, On your IOS device, run EZCast->Tap Search to search EZMusi->Tap EZMusicxxxxx in the device list to connect. Select Music-> Tap Edit->Tap Add, then select music files to add to the EZCast Playlist. Tap Edit



Tap Add



Select music files to add to the EZCast Playlist.



AirPlay

Step 1, On your IOS device, go to Settings-> WiFi, connect to EZMusicxxxx.

Step 2, Swipe up from the bottom of your screen to access Control Center. Tap AirPlay, Tap the name of the Wireless Music Box you wish to AirPlay to. Now you can Airplay your music on your IOS device to Wireless Music Box.



Play music from USB drive

Step1, Connect your USB drive to the Wireless Music Box.

Step2, On your device, go to Settings-> WiFi, connect to EZMusicxxxx.

Step3, On your device, run EZCast->Tap Search to search EZMusi->Tap EZMusicxxxxx in the device list to connect.

Step4, Tap Airdisk to find and play music files on your USB drive.



Listen internet radio on Wireless Music Box

Step1, Tap AirSetup to allow your Wirelss Music Box connect to internet.

Step2, Tap Radio to listen internet radio.



Setting Wireless Music Box

Tap AirSetup to Setting Wireless Music Box. Here you can modify the password, change the audio output mode, connect to internet and upgrade your Wireless Music Box.





Connect to Speaker

This Wireless Music Box can support L/R Audio and S/PDIF, you can connect the wireless music Box to Speaker with L/R audio cable or optical cable.

Power on

Connect the wireless music Box to power adapter(5V) with Micro-USB cable. Wireless music Box will boot automatically after connect to the power outlet.

SSID and Password

The SSID of Wireless Music Box is EZMusicxxxx, and the default password is 00000000.

EZCast on Android

• System requirements

Android 4 0 ICS or later with 1GB RAMat least

Download

1. You can use QR code scanner app to scan the QR code on display, then you will be redirected to download our app



2. Or you can search the App name "EZCast" in Google Play. (http://goo.gl/1usQ23)